



## NDS3508B Tuner to IP Gateway

### User's Manual--SPTS



# DIRECTORY

|   |           |
|---|-----------|
| <b>CHAPTER 1 PRODUCT OUTLINE.....</b>     | <b>1</b>  |
| 1.1 Outline.....                          | 1         |
| 1.2 Features.....                         | 1         |
| 1.3 Inner Principle.....                  | 1         |
| 1.4 Specifications.....                   | 2         |
| 1.5 Appearance and Description.....       | 2         |
| <b>CHAPTER 2 INSTALLATION GUIDE .....</b> | <b>5</b>  |
| 2.1 Acquisition Check.....                | 5         |
| 2.2 Installation Preparation.....         | 5         |
| 2.3 Wire's Connection.....                | 7         |
| <b>CHAPTER 3 WEB NMS OPERATION.....</b>   | <b>8</b>  |
| 3.1 login.....                            | 8         |
| <b>CHAPTER 4 WEB NMS OPERATION.....</b>   | <b>9</b>  |
| 3.1 login.....                            | 9         |
| 3.2 Operation.....                        | 9         |
| <b>CHAPTER 5 TROUBLESHOOTING .....</b>    | <b>18</b> |
| <b>CHAPTER 6 PACKING LIST.....</b>        | <b>19</b> |

# Chapter 1 Product Outline

## 1.1 Outline

NDS3508B Tuner to IP Gateway is a head-end interface-conversion device which supports MPTS(Bypass) output and SPTS output switchable in Web GUI. It supports 24 MPTS output(24 FTA tuner inputs)+3 MPTS output(2 ASI inputs and 1 USB input) or 1024 SPTS output over UDP and RTP/RTSP protocol. It is integrated with tuner demodulation (or ASI input) and gateway function, which can demodulate the signal from 24 FTA tuners into IP package, or directly convert the TS from ASI inputs or USB input into IP package, then output the IP package through different IP address and ports. BISS function is also embedded to descramble the programs from tuner inputs.


## 1.2 Features

- **Support 24 or 16 FTA DVB- S/S2/S2X or DVB-C/T/T2/ISDB-T Multi-Mode Switchable tuner inputs, 2 ASI inputs, 1USB input(TS file Playing, FTA 32, USB 2.0)**
- **Support BISS descrambling for tuner inputs**
- **Support DisEqc function**
- **24 MPTS output+3 MPTS output(2 ASI inputs and 1 USB port) or 1024 SPTS output (MPTS and SPTS output switchable in Web GUI)**
- **2 DATA output ports (IP address and port number of DATA1 and DATA2 are different), up to 900Mbps---SPTS**
- **2 independent DATA output ports, DATA1 ( 512 SPTS output ) + DATA2 ( 512 SPTS output )**
- **MPTS is pass-through mode, the first 12 tuner-input signals will be outputted from DATA 1, the rest 12 tuner-input signals will be outputted from DATA 2; The 2 ASI-input signals and 1 USB-input signal can be chosen to output via DATA 1 or DATA 2**
- **ASI out is useless in SPTS out mode, and ASI out can be the bypass output of**

one of the 27 input signals(24 tuner inputs, 2 ASI inputs and 1 USB port) in MPTS out mode, ASI out 1 and ASI out 2 are mirror ports to output the same one TS

- Support PID filtering, re-mapping (Only for SPTS output)
- Support “Null PKT Filter” function (Only for MPTS output)
- Support Web operation, reboot in Web GUI after firmware upgrading

### 1.3 Inner Principle




### 1.4 Specifications

| Input     |         | 24 tuners inputs +2 ASI inputs +1 USB inputs |   |
|-----------|---------|--|---|
| Satellite | DVB-S   | Frequency In                                 | 950~2150MHz   |
|           |         | Symbol rate                                  | 0.5~45Msp   |
|           |         | Signal Strength                              | - 65- -25dBm  |
|           |         | FEC  | 1/2, 2/3, 3/4, 5/6, 7/8   |
|           |         | Constellation                                | QPSK  |
|           |         | Max input bitrate                            | ≤125 Mbps   |
|           | DVB-S2  | Frequency In                                 | 950~2150MHz   |
|           |         | Symbol rate                                  | QPSK/8PSK /16APSK :0.5~45 Msp<br>32APSK: 0.5~34Msp;   |
|           |         | FEC  | QPSK: 1/2, 3/5, 2/3, 3/4, 4/5, 5/6, 8/9, 9/10<br>8PSK: 3/5, 2/3, 3/4, 5/6, 8/9, 9/10<br>16APSK: 2/3, 3/4, 4/5, 5/6, 8/9, 9/10<br>32APSK: 3/4, 4/5, 5/6, 8/9, 9/10 |
|           |         | Constellation                                | QPSK, 8PSK, 16APSK, 32APSK  |
|           |         | Max input bitrate                            | ≤125 Mbps   |
|           | DVB-S2X | Frequency In                                 | 950~2150MHz   |

|  |              |   |   |
|--|--------------|---|---|
|  |              | Symbol rate   | QPSK/8PSK /16APSK :0.5~45 Msps<br>8APSK: 0.5~40Msps<br>32APSK: 0.5~34Msps   |
|  |              | FEC   | QPSK: 1/2, 3/5, 2/3, 3/4, 4/5, 5/6, 8/9, 9/10, 13/45, 9/20, 11/20<br>8PSK: 3/5, 2/3, 3/4, 5/6, 8/9, 9/10<br>8APSK: 5/9-L, 26/45-L<br>16APSK: 2/3, 3/4, 4/5, 5/6, 8/9, 9/10, 1/2-L, 8/15-L, 5/9-L, 26/45, 3/5, 3/5-L, 28/45, 23/36 , 2/3-L, 25/36, 13/18, 7/9, 77/90<br>32APSK: 3/4, 4/5, 5/6, 8/9, 9/10, 2/3-L, 32/45, 11/15, 7/9 |
|  |              | Constellation   | QPSK, 8PSK, 8APSK, 16APSK, 32APSK   |
|  |              | Max input bitrate   | ≤125 Mbps   |
| Multi-Mode<br>Switchable<br>Tuner Inputs | DVB-C        | Standard  | J.83A(DVB-C), J.83B, J.83C  |
|  |              | Frequency In  | 50~960MHz   |
|  |              | Constellation   | 16/32/64/128/256 QAM  |
|  | DVB-T/T2     | Frequency In  | 50~960MHz   |
|  |              | Bandwidth   | 6/7/8 M bandwidth   |
| ISDB-T                                   | Frequency In | 50~960MHz   |   |
| <b>BISS Descrambling</b>                 |              | Mode 1, Mode E  |   |
| <b>Output</b>                            |              | 1024 SPTS IP output over UDP and RTP/RTSP protocol through DATA1 and DATA2 port (IP address and port number of DATA1 and DATA2 are different) , Unicast and Multicast |   |
|  |              | 27 MPTS IP output (for Tuner/ASI/USB bypass) over UDP and RTP/RTSP protocol through DATA1 and DATA2 port, Unicast and Multicast                                       |   |
|  |              | 2 ASI outputs(MPTS out mode only, mirror ports to output the same one TS)   |   |
| <b>System</b>                            |              | Web based management  |   |
|  |              | Ethernet software upgrade   |   |
| <b>Miscellaneous</b>                     |              | Dimension   | 482mm×270mm×44mm (W×L×H)  |
|  |              | Environment   | 0~45℃(work); -20~80℃ (Storage)  |
|  |              | Power requirements  | 100~240VAC, 50/60Hz   |


## 1.5 Appearance and Description

Front Panel Illustration:



|   |   |
|---|---|
| 1 | ASI input ports   |
| 2 | ASI output ports  |
| 3 | DATA1&2: IP out ports   |
| 4 | NMS port: Network management interface, <b>NMS IP:192.168.0.136</b> |
| 5 | USB port for TS input by TS file playing                            |
| 6 | LCD   |
| 7 | Key buttons for LCD operations                                      |
| 8 | Power/Run/Alarm indicators  |
| 9 | Power switch  |

### Rear Panel Illustration



|   |                                 |
|---|---------------------------------|
| 1 | 24 channels of RF IN Interfaces |
| 2 | Power Socket                    |
| 3 | Grounding Wire                  |

## Chapter 2 Installation Guide

### 2.1 Acquisition Check

When users open the package of the device, it is necessary to check items according to packing list. Normally it should include the following items:

- NDS3508B Tuner to IP Gateway
- Grounding Cable
- RF In and Loop Out Cable
- Power Cord

If any item is missing or mismatching with the list above, please contact local dealer.


### 2.2 Installation Preparation

When users install device, please follow the below steps. The details of installation will be described at the rest part of this chapter. Users can also refer rear panel chart during the installation.

The main content of this chapter including:

- Checking the possible device missing or damage during the transportation
- Preparing relevant environment for installation
- Installing gateway
- Connecting signal cables
- Connecting communication port (if it is necessary)

#### 2.2.1 Device's Installation Flow Chart Illustrated as following:



#### 2.2.2 Environment Requirement

| Item                    | Requirement   |
|-------------------------|---|
| Machine Hall Space      | When user installs machine frame array in one machine hall, the distance between 2 rows of machine frames should be 1.2~1.5m and the distance against wall should be no less than 0.8m.   |
| Machine Hall Floor      | Electric Isolation, Dust Free<br>Volume resistivity of ground anti-static material: $1 \times 10^7 \sim 1 \times 10^{10} \Omega$ , Grounding current limiting resistance: 1M<br>(Floor bearing should be greater than $450 \text{Kg/m}^2$ ) |
| Environment Temperature | 5~40°C(sustainable ) , 0~45°C(short time) ,<br>installing air-conditioning is recommended   |
| Relative Temperature    | 20%~80% sustainable 10%~90% short time  |
| Pressure                | 86~105KPa   |
| Door & Window           | Installing rubber strip for sealing door-gaps and dual level glasses for window   |
| Wall                    | It can be covered with wallpaper, or brightness less paint.   |
| Fire Protection         | Fire alarm system and extinguisher  |
| Power                   | Requiring device power, air-conditioning power and lighting power are independent to each other. Device power requires AC power 100V-240V 50/60Hz 2A. Please carefully check before running.  |

### 2.2.3 Grounding Requirement

- All function modules' good grounding designs are the basis of reliability and stability of devices. Also, they are the most important guarantee of lightning arresting and interference rejection. Therefore, the system must follow this rule.
- Coaxial cable's outer conductor and isolation layer should keep proper electric conducting with the metal housing of device.
- Grounding conductor must adopt copper conductor in order to reduce high frequency impedance, and the grounding wire must be as thick and short as possible.



- Users should make sure the 2 ends of grounding wire well electric conducted and be antitrust.
- It is prohibited to use any other device as part of grounding electric circuit
- The area of the conduction between grounding wire and device's frame should be no less than 25mm<sup>2</sup>.

### **2.2.4 Frame Grounding**

All the machine frames should be connected with protective copper strip. The grounding wire should be as short as possible and avoid circling. The area of the conduction between grounding wire and grounding strip should be no less than 25mm<sup>2</sup>.

### **2.2.5 Device Grounding**

Connecting the device's grounding rod to frame's grounding pole with copper wire.

## **2.3 Wire's Connection**

The grounding wire conductive screw is located at the right end of rear panel, and the power switch, fuse, power supply socket is just beside ,whose order goes like this, power switch is on the left ,power supply socket is on the right and the fuse is just between them.

- **Connecting Power Cord**

User can insert one end into power supply socket, while insert the other end to AC power.

- **Connecting Grounding Wire**

When the device solely connects to protective ground, it should adopt independent way, say, share the same ground with other devices. When the device adopts united way, the grounding resistance should be smaller than 1Ω.

---

**⚠ Caution:**

**Before connecting power cord to NDS3508B Tuner to IP Gateway, user should set the power switch to “OFF”.**

---

## Chapter 3 Keyboard Operation

The front panel is an user-operating interface for partial menu items. Users can make some basic operations, such as checking tuner locking status and checking & setting NMS IP etc.

The detailed operations go as follows:

Keyboard Function Description:

**ENTER:** To activate the parameters which need modifications, or to confirm the change after modification.


**MENU:** To cancel presently entered value, resume previous setting and return back to former menu.

**LEFT/RIGHT:** To move the “▶” to choose or set the parameters.

**UP/DOWN:** To modify activated parameter or page up/down when parameter is inactivated.

**LOCK:** To Lock the screen / cancel the lock status. After pressing Lock key, the system will ask the users whether to save the present setting or not. If not, the LCD will display the current configuration status.

### 3.1 LCD Menu Tree



## Chapter 4 WEB NMS operation

User can only control and set the configuration in computer by connecting the device to web NMS Port. User should ensure that the computer's IP address is different from the NDS3508B's IP address; otherwise, it would cause IP conflict.

### 3.1 login

The default IP of this device is 192.168.0.136.

Connect the PC and the device with net cable, and use ping command to confirm they are on the same network segment.

I.G. the PC IP address is 192.168.99.252, we then change the device IP to 192.168.99.xxx (xxx can be 0 to 255 except 252 to avoid IP conflict).

Use web browser to connect the device with PC by inputting this device's IP address in the browser's address bar and press Enter.

It displays the Login interface as Figure-1. Input the Username and Password (Both the default Username and Password are "admin".) and then click "Login" to start the device setting.



Figure-1

### 3.2 Operation

#### Summary → Status

When we confirm the login, it displays the status interface as Figure-2



Figure-2

System information

User can click any item here to enter the corresponding interface to check information or set the parameters.

**Parameters → Tuner** (DVB-C/T/T2/ISDB-T multi-mode switchable tuner inputs for example)

Click “Tuner” to enter the Web GUI where users can check the input status of all tuner inputs and set the tuner parameters. (Figure-3)




Figure-3

**Parameters → TS config**

Click “TS config” to enter the Web GUI where users can check and select the programs from all input channels. (Figure-4)

➤ **TS Config→DATA 1/ DATA 2:**

Choose “DATA 1/DATA2” to enter the corresponding interface where users can select the DATA1 or DATA2 to output the specific SPTS (Figure-4) .




Figure-4

➤ **TS Config→Stream Select:**

Click “Stream select” to enter the Web GUI where users can select programs to get multiplexed out and modify program info. (Figure-5)




Figure-5

Configure ‘Input Area’ and ‘Output Area’ with buttons in ‘Operation Area’. Instructions are as below:

- CA Filter** : To filter/not filter the source CA information

PID Remap : To enable/disable the PID remapping

**Refresh Input** To refresh the input program information

**Refresh Output** To refresh the output program information

**====>** Select one input program first and click this button to transfer the selected program to the right box to output.

**<====** Similarly, user can cancel the multiplexed programs from the right box.

**All Input** To select all the input programs

**All Output** To select all the output programs

**Parse program** To parse programs  time limitation of parsing input programs

➤ **Program Modification:**

The multiplexed program information can be modified by clicking the program name in the ‘output’ area. For example, when clicking **1: TV-101 <=CH1\_Tuner 1 [1001] =>224.2.2.2000**, it triggers a dialog box as below where users can edit the output ip address, port and choose Biss Key etc.

➤ **TS Config→General:**

From the TS Config menu on up side of the webpage, clicking “General”, it displays the interface where users can choose different character encoding for program names. (Figure-6)




Figure-6

➤ **TS Config→Biss:**

Click “Biss” to enter the Web GUI where users can configure BISS keys to descramble the specific programs (Figure-7).





Figure-7

Users can set BISS parameters by clicking ”Add” button.



**Parameters → USB media:**

Under USB Media page, user can play the TS files from the USB disk. Play Mode is select-able as the below list shows. After playing the files, the programs in the .ts files can be multiplexed out in TS Config page (Figure-8).






Figure-8

**Detailed Explanation:**

**Play Mode:** User can select a play mode for the \*.ts files as needed before playing the \*.ts file and specify a video under ‘Single file’ / ‘Single loop’ mode and press “Apply” and “Start” button to start play. While under ‘Play all’ / ‘Loop all’ mode, it automatically plays files from first to end. Loop means that it will pay the selected files round.

**Auto Play:** If ticked, the device will automatically play the .ts files as per the saved setting after reboot.

The .ts files can also be generated by our TS Creator software. If needed, users can contact our technician to get the software.

**System → Network:**

Click “Network” to enter the Web GUI as Figure-9 where to set network parameters.




Figure-9



**System → Password:**

Click “Password” to enter the Web GUI as Figure-11 where to set the login account and password for the web NMS.




Figure-11

**System → Configuration:**

Click “Configuration” to enter the Web GUI as Figure-12 where to save /restore/Factory Set/Backup/Load your configurations.




Figure-12

**System → Firmware:**

Click “Firmware” to enter the Web GUI as Figure-13 where to update firmware for the device.




Figure-13

### System → Log:

Click “Log” to enter the Web GUI as Figure-14 where to check the logs of the device.




Figure-14

### System → Reboot:

Click “Reboot” to reboot the device when it is needed.




Figure-15

## Chapter 5 Troubleshooting

DEXIN's ISO9001 quality assurance system has been approved by CQC organization. For guarantee the products' quality, reliability and stability. All DEXIN products have been passed the testing and inspection before ship out factory. The testing and inspection scheme already covers all the Optical, Electronic and Mechanical criteria which have been published by DEXIN. To prevent potential hazard, please strictly follow the operation conditions.

### Prevention Measure

- Installing the device at the place in which environment temperature between 0 to 45 °C
- Making sure good ventilation for the heat-sink on the rear panel and other heat-sink bores if necessary
- Checking the input AC within the power supply working range and the connection is correct before switching on device
- Checking the RF output level varies within tolerant range if it is necessary
- Checking all signal cables have been properly connected
- Frequently switching on/off device is prohibited; the interval between every switching on/off must greater than 10 seconds.

### Conditions need to unplug power cord

- Power cord or socket damaged.
- Any liquid flowed into device.
- Any stuff causes circuit short
- Device in damp environment
- Device was suffered from physical damage
- Longtime idle.
- After switching on and restoring to factory setting, device still cannot work properly.
- Maintenance needed

## Chapter 6 Packing list

- NDS3508B Tuner to IP gateway
- Grounding cable
- RF In and Loop Out Cable
- Power cord