








# iGame Center INSTRUCTION

# Main Interface – Display the status of PC components



-  Main Interface
-  My PC
-  Lighting Synchronization
-  Monitoring Center
-  Setting
-  Minimize
-  Turnoff


# My PC – Display connected device




Device  
Box

Each connected device will be shown in each box on screen.


# Device Setting – Performance adjusting or additional function adjusting (e.g. lighting)



Additional Function




Main Function



Adjust video card clock / custom fan speed

# Monitor Setting – Custom your LCD(Vulcan/Kudan available)



## LCD Function

- Display custom content (need to use the USB 2.0 data cable to connect the head of the graphics card with the motherboard of nine-pin interface)
- Display custom text
- Display real-time data
- Display system time
- Display mode selection
- Screen ON-OFF
- Adjust display direction adjustment
- Adjust screen brightness


# Light Setting— adjust device lighting



Custom video card light effects


# Lighting Synchronization



– overall lighting adjustment



Click button in the PC case to bind / unbind.  
Click red dot under each mode to adjust color.

# Monitoring Center – check PC status



Click   to change display style



# Setting– Software basic settings



Adjust auto-start / language setting.